



NOTE:

1. Panels should always be lapped against prevailing winds.
2. The above fastening patterns are typical and may not be appropriate for all applications. Consult a Professional Engineer for specific requirements.
3. $\frac{1}{8}$ " x $\frac{1}{2}$ " tape sealant shall be used at all side laps when used as a roof panel.
4. Side lap fasteners are required. Typical spacing is 12", however this spacing may not be appropriate for all applications. Consult a Professional Engineer for specific requirements.
5. DO NOT USE NAILS FOR ANY PANEL ATTACHMENT.

Job Name _____ Contractor _____

Date _____ Notes _____