
- Using the 36" straight edge provided, set it against the wall (as illustrated). 1.
- Using the 12" rule provided, measure the distance (rise) from the edge of the yardstick at the 2. 18" mark straight in to the face of the parapet.
- Repeat steps 1 and 2 in several more areas along the arch. Record these measurements in the 3. boxes provided. We will calculate the radius from these measurements.

NOTE! If the measured rise dimensions vary by $\frac{1}{2}$ or over, call Engineering Dept. at 800-323-1960 for further instructions

Fill in the general information below and fax this sheet back to 800-722-7150.



PLAN VIEW

NOTE! INDICATE PROPER RADIUS CONDITION BY CIRCLING APPROPIATE OUTSIDE FACE.

г	'n	\sim	16	$\overline{}$	_
м	'ĸ	O.	11-	(Γ:
	٠,	•	,,	. .	

ARCHITECT:

ROOFING CONTRACTOR:

REPRESENTATIVE/DISTRIBUTOR:



Phone: 800-323-1960 Fax: 800-722-7150

www.pac-clad.com e-mail: info@pac-clad.com DATE: 07/23/10 DRN BY: JJC CKD BY: SAK

SHT.# OF

DWG# 41810-12110