



PANEL PROFILE



APPLICATION →
PREVAILING WIND ←



NOTE:

1. Panels should always be lapped against prevailing winds.
2. The above fastening patterns are typical and may not be appropriate for all applications. Consult a Professional Engineer for specific requirements.
3. $\frac{1}{8}$ " x $\frac{1}{2}$ " tape sealant shall be used at all side laps when used as a roof panel.
4. Side lap fasteners are required. Typical spacing is 18", however this spacing may not be appropriate for all applications. Consult a Professional Engineer for specific requirements.
5. When using this panel in a roofing application, it should be lapped two corrugations. Panel may be lapped one corrugation when used in a siding application.
6. DO NOT USE NAILS FOR ANY PANEL ATTACHMENT.

Job Name:	
Date:	
Contractor:	
Notes:	